

The Youth Leader's Resource for Fun Patches and other great things!
PO Box 8669 Fayetteville, Arkansas USA 72703 479-927-0355

Patch Iron-On Instructions

We have made the application of your patches even SNAPPIER! Nearly all of our patches have an IRON-ON BACKING. Check the patch description for IRON-ON or call if you have questions.

HOW TO IRON-ON YOUR SNAPPYLOGOS PATCHES:

- 1. Pre-heat your iron to the Cotton/Linen setting; no steam.
- 2. Test your fabric. Check your care instructions to be sure your fabric can handle a HOT iron. Remember Nylon, felt, and other delicate fabrics may burn under the hot iron.
- 3. Work on top of a hard surface such as a heat resistant cutting board (wood) or phone book.
- 4. Layout the garment or area of application.
- 5. Place the patch in desired location, cover with a thin pressing cloth or parchment paper.
- 6. Press and hold the iron for 30 seconds. Remove the iron and check fabric & patch. Cover and press again for 30 seconds.
- 7. Let cool and check the corners, apply additional heat if necessary. Iron temperatures may vary, so if necessary press for an additional 30 seconds. Cool and test corners.
- 8. Wash inside-out with cool water and medium dryer.

Hints:

Remember do not attempt to iron patches onto NYLON jackets, or NYLON totebags. For this type of application we might suggestion ES6000 Glue, it is a very useful for many types of uses and will glue just about anything.

If you have any questions, we are here to help. 800-472-8866 Office Hours: Monday-Friday 8:30 – 5:00 CST